


Odkurzacz automatyczny



Tebas 7310



Tebas 7311 Battery



Odkurzacz automatyczny Tebas 7310 i Tebas 7311 Battery



kod -Code	Numer części - Part number	Nazwa - Part description	Cena katalogowa netto w EUR
30180	18	Square power supply. Single timer	190,03
30591		Floating battery pack. 8S1P for 7311 battery cleaner	129,09
33111	20	Machine end floating cord. 3m long. Grey	39,74
33291	19	Floating cord with MOLEX connector. 13m long. Grey	134,14
35011	21	square swivel, light grey color	49,68
36003	25	Power cord. VDE Europe standard	13,78
36113		1A charger for 8S battery for 7311 battery cleaner	56,72
64151	20	Machine end floating cord. 3m long. Grey for 7311 battery cleaner	39,74
71000	1	Top shell. Dark grey	38,46
71020	3	Top lid. Smoke	22,02
71040	4	Impeller	13,77
71050	5	Pump motor block	361,85
71052	5	Pump motor block for 7311 battery cleaner	361,85
71070	6	Pump cover lid. Black	16,54
71080	7	Handle. Black	20,65
71090	8	Geared roller tube assembly. Black	42,72
71100	9	Bottom chassis. Charcoal grey	82,39
71110	10	Fast drain flap. Charcoal grey	13,77
71120	11	Side support assembly. L. Black	31,69
71130	12	Drive belt track. 2pcs as a set. Black	48,25
71140	13	Geared wheel. 4pcs as a set. Grey	20,65
71142		Geared wheel with 2 tapped holes. 4pcs as a set.	20,65
71150	14	Front roller assembly. Grey and black	26,16
71160	15	Side support assembly. R. Black	31,69
71170	28	Fine filtration pad. Single side. 2pcs as a set, retail	24,38
71180	27	PVC brush set, 5pcs as a set	69,01
71190	2	Debris basket, fine mesh assembly	79,07